

Owner's Manual Guide for the Refrigerator

Before using the Refrigerator:

- Before plugging the Refrigerator make sure that both the voltage and the frequency of the current supply are convenient to the usage of the appliance (Voltage and Frequency of the appliance are indicated on the outside packing carton and on the name plate at the back of the appliance)
- Make sure that the place where you install the Refrigerator is dry, well ventilated and not exposed to direct sunlight
- Adjust the leveling of the Refrigerator using the leveling screws in order for the appliance to be slightly inclined backward
- Keep a distance of minimum 15 cm between the Refrigerator and the surrounding walls or other appliances
- It is important not to plug the Refrigerator to electricity before 4 hours from arrival to the house
- It is recommended to wait for another 4 hours after plugging the Refrigerator before placing the food

Temperature Adjustment:

The thermostat box inside the refrigerator cabinet is used to adjust the temperature of the refrigerator and freezers compartments to the desired level

- It is advisable to keep the thermostat on level "1" or "2" in the summer to avoid formation of ice due to the high intensity of humidity in the air while keeping the thermostat on level "3" or "4" in winter. Levels "5" and above are to be used in special cases and for short period of times if super cooling is required
- In case of formation of thick layer of ice at the back of the refrigerator compartment, adjust the thermostat to position "0" till ice is totally defrosted

Ice Defrosting:

- The Refrigerator you own is designed to automatically defrost ice that can form at the back of the compartment. Heat generated from the compressor is used to evaporate water caused by the defrosted ice
- In some rare cases and due to high intensity of humidity in the air, thick layer of ice can be formed at the back of the refrigerator. In this case, adjust the thermostat to position “0” till the ice is totally defrosted
- To reduce the formation of ice inside the cabinet, be sure to pack well the food and minimize the opening of the Refrigerator doors
- It is mandatory to unplug the Refrigerator before the ice defrosting process
- Do not use an electric heater to assist defrosting
- After finishing the ice defrosting process, wait for four hours after plugging the Refrigerator before loading the food

General Recommendations:

- The best temperature for food storage for long periods is -18°C
- Avoid placing hot food in the Refrigerator
- Avoid frequent opening of the Refrigerator doors
- Avoid freezing glass bottles and soft drinks
- If the Refrigerator is not to be used for a long time, it is recommended to switch it off and leave the doors open
- Before cleaning, always unplug the Refrigerator. Do not use caustic or abrasive agents or soap for cleaning
- The compressor and the condenser should be freed of dust once a year with a brush or vacuum cleaner
- It is recommended to wrap the food in plastic bags or aluminum foils to isolate the content from direct contact with cold air
- In case of power failure, the Refrigerator you own is designed to preserve the low temperature for the longest period of time taking into consideration to avoid frequent opening of the Refrigerator doors